



A.Y. McDonald Mfg. Co. Small Wrap/Patch Repair Clamps

Installation Instructions

Preparation:

1. Check diameter of pipe to make sure you are using the correct size clamp.
2. Clean pipe to remove dirt and corrosion from the surface.
3. Place marks on the pipe to reference the leak. Use these marks to assure that the clamp is properly centered.

Installation:

1. Back off the nuts to the ends of the bolts, **but do not remove them**. Separate the clamp.
2. Center the clamp gasket over the area that needs repaired. Make sure the clamp gasket extends well past the damaged area.
3. Relocate the bolt heads securely into their receiving lugs. Tighten bolts to torque range listed on repair clamp.
4. Pressure test for leaks before backfilling.



WARNING: It is unlawful in **CALIFORNIA & VERMONT** (effective 1/1/2010); **MARYLAND** (effective 1/1/2012); **LOUISIANA** (effective 1/1/2013) and the **UNITED STATES OF AMERICA** (effective 1/4/2014) to use any product in the installation or repair of any public water system or any plumbing in a facility or system that provides water for human consumption if the wetted surface area of the product has a weighted average lead content greater than 0.25%. This prohibition does not extend to service saddles used in California, Louisiana or under USA Public Law 111-380.

3210-630

800.292.2737 | sales@aymcdonald.com | aymcdonald.com

4/22



A.Y. McDonald Mfg. Co. Small Wrap/Patch Repair Clamps

Installation Instructions

Preparation:

1. Check diameter of pipe to make sure you are using the correct size clamp.
2. Clean pipe to remove dirt and corrosion from the surface.
3. Place marks on the pipe to reference the leak. Use these marks to assure that the clamp is properly centered.

Installation:

1. Back off the nuts to the ends of the bolts, **but do not remove them**. Separate the clamp.
2. Center the clamp gasket over the area that needs repaired. Make sure the clamp gasket extends well past the damaged area.
3. Relocate the bolt heads securely into their receiving lugs. Tighten bolts to torque range listed on repair clamp.
4. Pressure test for leaks before backfilling.



WARNING: It is unlawful in **CALIFORNIA & VERMONT** (effective 1/1/2010); **MARYLAND** (effective 1/1/2012); **LOUISIANA** (effective 1/1/2013) and the **UNITED STATES OF AMERICA** (effective 1/4/2014) to use any product in the installation or repair of any public water system or any plumbing in a facility or system that provides water for human consumption if the wetted surface area of the product has a weighted average lead content greater than 0.25%. This prohibition does not extend to service saddles used in California, Louisiana or under USA Public Law 111-380.

3210-630

800.292.2737 | sales@aymcdonald.com | aymcdonald.com

4/22