




IMPORTANT NOTICE - READ CAREFULLY

Flange Assembly

Installation Instructions

1. Keep flange assembly clean and free from dirt and debris.
2. Protect flange assembly from freezing.
3. Always use an approved sealant or teflon tape on tapered pipe threads.
4. Use a snug fitting smooth jaw wrench on the wrenching flat. Do not wrench the body or flange.
- 5.

a) Keep flange extended with spacer tied in place during installation and pressurization. Place gasket between flange and meter.



b) To remove water meter, remove bolts attaching flange to meter, pull spacer up out of groove and retract flange.

6. PRESSURE TEST FOR LEAKS BEFORE BACKFILLING.

7. USE ONLY ON COLD WATER SERVICES.

(OVER)

3210-639

800.292.2737 | sales@aymcdonald.com | aymcdonald.com

11/18




IMPORTANT NOTICE - READ CAREFULLY

Flange Assembly

Installation Instructions

1. Keep flange assembly clean and free from dirt and debris.
2. Protect flange assembly from freezing.
3. Always use an approved sealant or teflon tape on tapered pipe threads.
4. Use a snug fitting smooth jaw wrench on the wrenching flat. Do not wrench the body or flange.
- 5.

a) Keep flange extended with spacer tied in place during installation and pressurization. Place gasket between flange and meter.



b) To remove water meter, remove bolts attaching flange to meter, pull spacer up out of groove and retract flange.

6. PRESSURE TEST FOR LEAKS BEFORE BACKFILLING.

7. USE ONLY ON COLD WATER SERVICES.

(OVER)

3210-639

800.292.2737 | sales@aymcdonald.com | aymcdonald.com

11/18




IMPORTANT NOTICE - READ CAREFULLY

Flange Assembly

Installation Instructions

1. Keep flange assembly clean and free from dirt and debris.
2. Protect flange assembly from freezing.
3. Always use an approved sealant or teflon tape on tapered pipe threads.
4. Use a snug fitting smooth jaw wrench on the wrenching flat. Do not wrench the body or flange.
- 5.

a) Keep flange extended with spacer tied in place during installation and pressurization. Place gasket between flange and meter.



b) To remove water meter, remove bolts attaching flange to meter, pull spacer up out of groove and retract flange.

6. PRESSURE TEST FOR LEAKS BEFORE BACKFILLING.

7. USE ONLY ON COLD WATER SERVICES.

(OVER)

3210-639

800.292.2737 | sales@aymcdonald.com | aymcdonald.com

11/18




IMPORTANT NOTICE - READ CAREFULLY

Flange Assembly

Installation Instructions

1. Keep flange assembly clean and free from dirt and debris.
2. Protect flange assembly from freezing.
3. Always use an approved sealant or teflon tape on tapered pipe threads.
4. Use a snug fitting smooth jaw wrench on the wrenching flat. Do not wrench the body or flange.
- 5.

a) Keep flange extended with spacer tied in place during installation and pressurization. Place gasket between flange and meter.



b) To remove water meter, remove bolts attaching flange to meter, pull spacer up out of groove and retract flange.

6. PRESSURE TEST FOR LEAKS BEFORE BACKFILLING.

7. USE ONLY ON COLD WATER SERVICES.

(OVER)

3210-639

800.292.2737 | sales@aymcdonald.com | aymcdonald.com

11/18



IMPORTANT NOTICE - READ CAREFULLY
Flange Assembly

Installation Instructions

**A.Y. McDonald waterworks products are designed for reliable service.
Like all brass products, however, they can be damaged by improper handling and use.**

CAUTIONS

1. Protect threads. Avoid loose fitting wrenches. Do not drop or impact.
2. Use extra care with high water pressures (over 100 PSIG) and pipe or tubing over 1". Consult factory if desired.
3. Inspect and test all joints and fittings before backfilling.
4. Backfill carefully so as to avoid damage to the service line and connections. Looping of the service lines is recommended to minimize strain.
5. DO NOT use Vaseline®, plumber's grease, or any other petroleum based product on seals or o-rings.

Damage caused by improper use and/or handling will void our warranty

(OVER)

WARNING: It is unlawful in CALIFORNIA & VERMONT (effective 1/1/2010); MARYLAND (effective 1/1/2012); LOUISIANA (effective 1/1/2013) and the UNITED STATES OF AMERICA (effective 1/4/2014) to use any product in the installation or repair of any public water system or any plumbing in a facility or system that provides water for human consumption if the wetted surface area of the product has a weighted average lead content greater than 0.25%. This prohibition does not extend to service saddles used in California, Louisiana or under USA Public Law 111-380.



IMPORTANT NOTICE - READ CAREFULLY
Flange Assembly

Installation Instructions

**A.Y. McDonald waterworks products are designed for reliable service.
Like all brass products, however, they can be damaged by improper handling and use.**

CAUTIONS

1. Protect threads. Avoid loose fitting wrenches. Do not drop or impact.
2. Use extra care with high water pressures (over 100 PSIG) and pipe or tubing over 1". Consult factory if desired.
3. Inspect and test all joints and fittings before backfilling.
4. Backfill carefully so as to avoid damage to the service line and connections. Looping of the service lines is recommended to minimize strain.
5. DO NOT use Vaseline®, plumber's grease, or any other petroleum based product on seals or o-rings.

Damage caused by improper use and/or handling will void our warranty

(OVER)

WARNING: It is unlawful in CALIFORNIA & VERMONT (effective 1/1/2010); MARYLAND (effective 1/1/2012); LOUISIANA (effective 1/1/2013) and the UNITED STATES OF AMERICA (effective 1/4/2014) to use any product in the installation or repair of any public water system or any plumbing in a facility or system that provides water for human consumption if the wetted surface area of the product has a weighted average lead content greater than 0.25%. This prohibition does not extend to service saddles used in California, Louisiana or under USA Public Law 111-380.



IMPORTANT NOTICE - READ CAREFULLY
Flange Assembly

Installation Instructions

**A.Y. McDonald waterworks products are designed for reliable service.
Like all brass products, however, they can be damaged by improper handling and use.**

CAUTIONS

1. Protect threads. Avoid loose fitting wrenches. Do not drop or impact.
2. Use extra care with high water pressures (over 100 PSIG) and pipe or tubing over 1". Consult factory if desired.
3. Inspect and test all joints and fittings before backfilling.
4. Backfill carefully so as to avoid damage to the service line and connections. Looping of the service lines is recommended to minimize strain.
5. DO NOT use Vaseline®, plumber's grease, or any other petroleum based product on seals or o-rings.

Damage caused by improper use and/or handling will void our warranty

(OVER)

WARNING: It is unlawful in CALIFORNIA & VERMONT (effective 1/1/2010); MARYLAND (effective 1/1/2012); LOUISIANA (effective 1/1/2013) and the UNITED STATES OF AMERICA (effective 1/4/2014) to use any product in the installation or repair of any public water system or any plumbing in a facility or system that provides water for human consumption if the wetted surface area of the product has a weighted average lead content greater than 0.25%. This prohibition does not extend to service saddles used in California, Louisiana or under USA Public Law 111-380.



IMPORTANT NOTICE - READ CAREFULLY
Flange Assembly

Installation Instructions

**A.Y. McDonald waterworks products are designed for reliable service.
Like all brass products, however, they can be damaged by improper handling and use.**

CAUTIONS

1. Protect threads. Avoid loose fitting wrenches. Do not drop or impact.
2. Use extra care with high water pressures (over 100 PSIG) and pipe or tubing over 1". Consult factory if desired.
3. Inspect and test all joints and fittings before backfilling.
4. Backfill carefully so as to avoid damage to the service line and connections. Looping of the service lines is recommended to minimize strain.
5. DO NOT use Vaseline®, plumber's grease, or any other petroleum based product on seals or o-rings.

Damage caused by improper use and/or handling will void our warranty

(OVER)

WARNING: It is unlawful in CALIFORNIA & VERMONT (effective 1/1/2010); MARYLAND (effective 1/1/2012); LOUISIANA (effective 1/1/2013) and the UNITED STATES OF AMERICA (effective 1/4/2014) to use any product in the installation or repair of any public water system or any plumbing in a facility or system that provides water for human consumption if the wetted surface area of the product has a weighted average lead content greater than 0.25%. This prohibition does not extend to service saddles used in California, Louisiana or under USA Public Law 111-380.