
Installation Instructions



IMPORTANT NOTICE - READ CAREFULLY Flare Thread McGrip Series Compression Connectors



The A.Y. McDonald Flare Thread McGrip Series compression system is a simple convenient method of connection for tube size service materials (copper or plastic).

The simple steps listed below will make your job easier and assure fast, safe, and watertight connections:

1. Service tubing should always be <u>snaked</u> in the ditch.

2" size 150 ft-lbs

- 2. Use a tube or pipe cutter to assure a square end. Make sure pipe is round. On copper tubing, use a rounding tool, if necessary. Surface should be clean and free of nicks.
- 3. Insert stiffeners must be used on all plastic tube except rigid PVC.
- **4.** Stab tube or pipe through the nut and into the socket of the valve or fitting until it bottoms out (Some fittings may or may not have a stop).
- **5.** Tighten the Flare Thread McGrip Series nut to the following minimum torques. Over torquing by 5-10 ft-lbs will not affect connection.

1-1/2" size 125 ft-lbs

6. PRESSURE TEST FOR LEAKS BEFORE BACKFILLING

7. Use only on cold water services.

3210-400

800.292.2737 | sales@aymcdonald.com | aymcdonald.com

**IMPORTANT NOTICE - READ CAREFULLY** 

3/22

Installation Instructions



Flare Thread McGrip Series Compression Connectors

The A.Y. McDonald Flare Thread McGrip Series compression system is a simple convenient method of connection for tube size service materials (copper or plastic).

The simple steps listed below will make your job easier and assure fast, safe, and watertight connections:

**1.** Service tubing should always be <u>snaked</u> in the ditch.

- 2. Use a tube or pipe cutter to assure a square end. Make sure pipe is round. On copper tubing, use a rounding tool, if necessary. Surface should be clean and free of nicks.
- 3. Insert stiffeners must be used on all plastic tube except rigid PVC.
- **4.** Stab tube or pipe through the nut and into the socket of the valve or fitting until it bottoms out (Some fittings may or may not have a stop).
- 5. Tighten the Flare Thread McGrip Series nut to the following minimum torques. Over torquing by 5-10 ft-lbs will not affect connection.

1-1/2" size 125 ft-lbs 2" size 150 ft-lbs

- 6. PRESSURE TEST FOR LEAKS BEFORE BACKFILLING
- 7. Use only on cold water services.


3210-400

800.292.2737 | sales@aymcdonald.com | aymcdonald.com

3/22



### IMPORTANT NOTICE - READ CAREFULLY Flare Thread McGrip Series Compression Connectors



The A.Y. McDonald Flare Thread McGrip Series compression system is a simple convenient method of connection for tube size service materials (copper or plastic).

The simple steps listed below will make your job easier and assure fast, safe, and watertight connections:

1. Service tubing should always be <u>snaked</u> in the ditch.

- 2. Use a tube or pipe cutter to assure a square end. Make sure pipe is round. On copper tubing, use a rounding tool, if necessary. Surface should be clean and free of nicks.
- 3. Insert stiffeners must be used on all plastic tube except rigid PVC.
- **4.** Stab tube or pipe through the nut and into the socket of the valve or fitting until it bottoms out (Some fittings may or may not have a stop).
- 5. Tighten the Flare Thread McGrip Series nut to the following minimum torques. Over torquing by 5-10 ft-lbs will not affect connection.

1-1/2" size 125 ft-lbs

2" size 150 ft-lbs

- 6. PRESSURE TEST FOR LEAKS BEFORE BACKFILLING
- 7. Use only on cold water services.

#### 3210-400

800.292.2737 | sales@aymcdonald.com | aymcdonald.com

3/22

3/22

# Installation Instructions



# IMPORTANT NOTICE - READ CAREFULLY Flare Thread McGrip Series Compression Connectors

Ĭ	Ш	1 COM	

The A.Y. McDonald Flare Thread McGrip Series compression system is a simple convenient method of connection for tube size service materials (copper or plastic).

The simple steps listed below will make your job easier and assure fast, safe, and watertight connections:

1. Service tubing should always be <u>snaked</u> in the ditch.

- 2. Use a tube or pipe cutter to assure a square end. Make sure pipe is round. On copper tubing, use a rounding tool, if necessary. Surface should be clean and free of nicks.
- 3. Insert stiffeners must be used on all plastic tube except rigid PVC.
- **4.** Stab tube or pipe through the nut and into the socket of the valve or fitting until it bottoms out (Some fittings may or may not have a stop).
- 5. Tighten the Flare Thread McGrip Series nut to the following minimum torques. Over torquing by 5-10 ft-lbs will not affect connection.

1-1/2" size 125 ft-lbs

- 6. PRESSURE TEST FOR LEAKS BEFORE BACKFILLING
- 7. Use only on cold water services.

800.292.2737 | sales@aymcdonald.com | aymcdonald.com

2" size 150 ft-lbs



#### **IMPORTANT NOTICE - READ CAREFULLY** Flare Thread McGrip Series Compression Connectors

A.Y. McDonald waterworks products are designed for reliable service. Like all brass products, however, they can be damaged by improper handling and use.

#### CAUTIONS:

- 1. Protect threads. Avoid loose fitting wrenches. Do not drop or impact.
- 2. Use extra care with high water pressures (over 100 PSIG) and pipe over 1". Consult factory if desired.
- 3. Inspect and test all joints, valves and fittings before backfilling.
- 4. Backfill carefully so as to avoid damage to the service line and connections. Looping of the service lines is recommended to minimize strain.
- 5. DO NOT use Vaseline®, plumber's grease, or any other petroleum based product on seals or o-rings.

#### DAMAGE CAUSED BY IMPROPER USE AND/OR HANDLING WILL VOID OUR WARRANTY

WARNING: It is unlawful in CALIFORNIA & VERMONT (effective 1/1/2010); MARYLAND (effective 1/1/2012); LOUISIANA (effective 1/1/2013) and the UNITED STATES OF AMERICA (effective 1/4/2014) to use any product in the installation or repair of any public water system or any plumbing in a facility or system that provides water for human consumption if the wetted surface area of the product has a weighted average lead content greater than 0.25%. This prohibition does not extend to service saddles used in California, Louisiana or under USA Public Law 111-380.

```
3210-400
```

800.292.2737 | sales@aymcdonald.com | aymcdonald.com



Installation Instructions

3/22

# **IMPORTANT NOTICE - READ CAREFULLY** Flare Thread McGrip Series Compression Connectors

A.Y. McDonald waterworks products are designed for reliable service. Like all brass products, however, they can be damaged by improper handling and use.

#### CAUTIONS:

- 1. Protect threads, Avoid loose fitting wrenches. Do not drop or impact.
- 2. Use extra care with high water pressures (over 100 PSIG) and pipe over 1". Consult factory if desired.
- 3. Inspect and test all joints, valves and fittings before backfilling.
- 4. Backfill carefully so as to avoid damage to the service line and connections. Looping of the service lines is recommended to minimize strain.
- 5. DO NOT use Vaseline®, plumber's grease, or any other petroleum based product on seals or o-rings.

#### DAMAGE CAUSED BY IMPROPER USE AND/OR HANDLING WILL VOID OUR WARRANTY

WARNING: It is unlawful in CALIFORNIA & VERMONT (effective 1/1/2010); MARYLAND (effective 1/1/2012); LOUISIANA (effective 1/1/2013) and the UNITED STATES OF AMERICA (effective 1/4/2014) to use any product in the installation or repair of any public water system or any plumbing in a facility or system that provides water for human consumption if the wetted surface area of the product has a weighted average lead content greater than 0.25%. This prohibition does not extend to service saddles used in California. Louisiana or under USA Public Law 111-380.





### **IMPORTANT NOTICE - READ CAREFULLY** Flare Thread McGrip Series Compression Connectors

A.Y. McDonald waterworks products are designed for reliable service. Like all brass products, however, they can be damaged by improper handling and use.

## CAUTIONS:

- 1. Protect threads. Avoid loose fitting wrenches. Do not drop or impact.
- 2. Use extra care with high water pressures (over 100 PSIG) and pipe over 1". Consult factory if desired.
- 3. Inspect and test all joints, valves and fittings before backfilling.
- 4. Backfill carefully so as to avoid damage to the service line and connections. Looping of the service lines is recommended to minimize strain.
- 5. DO NOT use Vaseline®, plumber's grease, or any other petroleum based product on seals or o-rings.

#### DAMAGE CAUSED BY IMPROPER USE AND/OR HANDLING WILL VOID OUR WARRANTY

WARNING: It is unlawful in CALIFORNIA & VERMONT (effective 1/1/2010); MARYLAND (effective 1/1/2012); LOUISIANA (effective 1/1/2013) and the UNITED STATES OF AMERICA (effective 1/4/2014) to use any product in the installation or repair of any public water system or any plumbing in a facility or system that provides water for human consumption if the wetted surface area of the product has a weighted average lead content greater than 0.25%. This prohibition does not extend to service saddles used in California. Louisiana or under USA Public Law 111-380.

#### 3210-400

800.292.2737 | sales@aymcdonald.com | aymcdonald.com

3/22



#### Installation Instructions **IMPORTANT NOTICE - READ CAREFULLY**

Flare Thread McGrip Series Compression Connectors

A.Y. McDonald waterworks products are designed for reliable service. Like all brass products, however, they can be damaged by improper handling and use.

# CAUTIONS:

- 1. Protect threads, Avoid loose fitting wrenches. Do not drop or impact.
- 2. Use extra care with high water pressures (over 100 PSIG) and pipe over 1". Consult factory if desired.
- 3. Inspect and test all joints, valves and fittings before backfilling.
- 4. Backfill carefully so as to avoid damage to the service line and connections. Looping of the service lines is recommended to minimize strain.
- 5. DO NOT use Vaseline®, plumber's grease, or any other petroleum based product on seals or o-rings.

# DAMAGE CAUSED BY IMPROPER USE AND/OR HANDLING WILL VOID OUR WARRANTY

